



- 1: Tachometer
- 2: Neutral Light
- 3: Charge Light
- 4: Instrument Lighting
- 5: Key Switch
- 6: Speedometer
- 7: Headlight Indicator
- 8: Flashing Light
- 9: Left Front Indicator
- 10: Headlight Bulb
- 11: Parking Light Bulb
- 12: Right Front Indicator
- 13: Left Front Indicator
- 14: Horn button
- 15: Low/High beam switch
- 16: High beam flash
- 17a: Front stop Switch
- 17b: Rear stop Switch

- 18: Starter button
- 19: Left/Right Turn signal switch
- 20: Engine Run/Stop
- 21: Points
- 22: Condensors
- 23: Horns
- 24: Horn relay
- 25: Neutral Switch
- 26: Flasher
- 27: Ignition Coils
- 28: Battery
- 29: Starter
- 30: Starter Relay

- 31: Fuse Box
- 32: Generator
- 33: Regulator
- 34: Left Rear Indicator
- 35: tail light/Brake light
- 36: Right Rear Indicator