



- 1. Right Front Turn Signal
- 2. Speedometer
- 3. Key Switch
- 4. Headlight Housing
- 5. Headlight Bulb
- 6. Parking Light Bulb
- 7. Tachometer
- 8. Left Front Turn Signal
- 9. Turn Signal Indicator
- 10. Instrument Lighting
- 11. High Beam Indicator
- 12. Neutral Light
- 13. Charge Light
- 14. Right Handlebar Assembly
- 15. Engine Run/Stop
- 16. Starter Button
- 17. Left Handlebar Assembly
- 18. High/Low/Park Switch
- 19. Headlight Switch
- 20. Turn Signal Control

- 21. Horn Button
- 22. Front Brake Light Switch
- 23. Right Coil
- 24. Left Coil
- 25. Horns
- 26. Neutral Light Switch
- 27. Resistors
- 28. Spark Plugs
- 29. Left Side Ignition Pick-up
- 30. Generator
- 31. Right Side Ignition Pick-up
- 32. Right Ignition Module
- 33. Left Ignition Module
- 34. Flasher Relay
- 35. Rear Brake Light Switch
- 36. Starter Motor
- 37. Starter Relay
- 38. Battery
- 39. Fuse Box
- 40. Voltage Regulator
- 41. Right Rear Turn Signal
- 42. Rear Light/Brake Light
- 43. Left Rear Turn Signal
- 44. Daytime Light Relay