



LEGEND

1. Headlight
2. Main light bulb
3. Terminal block with fuses
4. Distributing block
5. Light switch and horn button
6. Spark plug
7. Distributor
8. Contact breaker
9. Ignition coil
10. Speedometer and warning light bulbs
11. High beam indicator
12. Generator warning light
13. Neutral indicator
14. Oil pressure warning indicator
15. Horn
16. Stop light switch
17. Neutral indicator switch
18. Oil pressure switch
19. Ignition switch
20. Number plate and tail light
21. Plate illumination and stop light
22. Generator
23. Regulator
24. Battery
25. Starter motor relay
26. Starter motor

IGNITION SWITCH POSITION

0. Off
1. 30/30 Int.      15/54
2. 30/20 Int.      15/54
3. 30/30 Int.      15/54 50