

- 1. Speedometer (3W)
- 2. Tachometer (3W)
- 3. High beam indicator light (1.2W)
- 4. Oil pressure indicator light (1.2W)
- 5. Neutral indicator light (1.2W)
- 6. Low beam indicator light (1.2W)
- 7. Generator indicator light (1.2W)
- 8. Low beam (40W)
- 9. High beam (45W)
- 10. Right front turn signal indicator (1.2W)
- 11. Left front turn signal indicator (1.2W)
- 12. Engine start and stop switch

- 13. Light switch; w/stop device from position <<High-Low beam >> to position << Parking light >>
- 14. Switch; turn signal, horns, high beam flash
- 15. Horns
- 16. Front brake stop light switch
- 17. Flashing light relay
- 18. Rear brake light switch
- 19. Battery
- 20. Regulator
- 21. Rectifier
- 22. Alternator
- 23. Starter motor relay
- 24. Starter motor
- 25. Clutch cable switch
- 26. Left rear turn signal (21 W)
- 27. Rear brake stop light (21 W)
- 28. Number plate and parking light (5 W)
- 29. Right rear turn signal (21 W)

- 30. Flasher unit
- 31. Oil pressure switch
- 32. Neutral position switch
- 33. Terminal block with fuses (15 A)
- 34. 3-way connector
- 35. 4-way connector

- 36. Contact breaker
- 37. Coils
- 38. Ignition switch (3 positions)
- 39. 4-way connector
- 40. 2-way connector
- 41. Spark plugs

