



- 1. Speedometer (3 W)
- 2. Auxiliary light (5 W)
- 3. High beam indicator (1.2 W)
- 4. Oil pressure indicator (1.2 W)
- 5. Neutral indicator (1.2 W)
- 6. Headlights indicator (1.2 W)
- 7. Generator indicator (1.2 W)
- 8. Headlight low beam (40 W)
- 9. Headlight high beam (45 W)
- 10. R/H front turn signal (21 W)
- 11. L/H front turn signal (21 W)
- 12. Engine kill switch
- 13. Additional switch
- 14. Control switch: turn signals, lights and horn
- 15. Horns (7 amps consumption)
- 16. Front brake switch
- 17. High beam flash relay
- 18. Rear brake switch
- 19. Battery
- 20. Regulator
- 21. Rectifier
- 22. Alternator
- 23. Starter relay
- 24. Starter motor
- 25. Neutral switch
- 26. L/H rear turn signal
- 27. Taillight and stop light (5 W + 21 W)
- 28. License plate light (5 W + 5 W)
- 29. R/H rear turn signal
- 30. Turn signal flasher
- 31. Oil pressure switch
- 32.
- 33. Fuse holder (16 A fuses)
- 34. Connector 3-way
- 35. Connector AMP 4-way
- 36. Points
- 37. Ignition coils
- 38. Ignition switch (3 position)
- 39. Hazard light switch
- 40. Connector 2-way
- 41. Spark plugs
- 42. Light switch - High/Low/Park
- 43. R/H turn signal indicator (1.2 W)
- 44. L/H turn signal indicator (1.2 W)
- 45. Sidestand warning indicator (1.2 W)
- 46. Brake fluid warning light (1.2 W)
- 47. Fuel level indicator (1.2 W)
- 48. 4-way connector AMP
- 49. Connector
- 50. Brake fluid level sensor
- 51. Fuel level indicator
- 52. Electric fuel valve (2.5W)
- 53. Sidestand switch and ignition coil power disconnect
- 54. Flasher for sidestand warning light
- 55. Rear parking light (5 W/ (21 W)