




- Key
3. AMP 3-way diagnostic connector

7. Right cylinder HT ignition coil

8. Bank angle sensor

17. Falcon instrument panel

18. Engine oil pressure sensor

19. Engine oil temperature sensor

20. Speed sensor

21. 12V 330W altemator

22. Voltage regulator

24. Starter motor

25. 12V battery

26. Starter relay

32. Right control

33. Fuse box

41. IAW 15M control unit

42. Intake air temperature sensor

45. Left cylinder HT ignition coil

46. Injecton utilities relay

49. ECU relay

50. Fuel pump

51. Left injector

52. Right injector

53. Timing sensor (SEN813)

54. Head temperature sensor

55. Throttle position sensor

56. Absolute pressure sensor inside ECU.
- | | | |
|----|------------------------------------|------|
| F1 | ECU | 3 A |
| F2 | Pump, coils, injectors | 15 A |
| F3 | Charging the battery | 30 A |
| F4 | Key-controlled +12V, starter motor | 15 A |